

Oscilloscopes for PDV: Getting More out of your Scope


Stephen Mueller

Applications Engineering Manager
Stephen.Mueller@LeCroy.com



TELEDYNE LECROY
Everywhereyoulook™


Oscilloscope Block Diagram



- ✦ Amplifiers and attenuators scale the input signals amplitude to match the input range of the Analog to Digital Converter (ADC)
- ✦ The ADC samples the analog signal and converts the voltage into a digital number

Quantization Error

4x attenuation of signal produces 4x larger quantization steps = 2 bits less resolution!



Zooms of rising edges show quantization levels

Enhanced Resolution

Description


- ERES increases vertical resolution by filter the waveform
- Gain up to 3 bits of resolution in 1/2 bit steps

Usage

- Suitable for single-shot and repetitive waveforms
- Reduces noise
- Increases precision

Disadvantages

- Effective bandwidth decreased by 50% for every 1/2 bit gain



12-bit High Definition Technology – Teledyne LeCroy HDO6000



- ✦ Combination of
 - ✦ High Sample Rate 12-bit ADCs
 - ✦ High signal-to-noise input amplifiers
 - ✦ Low noise system architecture

- ✦ 16 times more resolution than traditional 8-bit scope

- ✦ Capture high frequency signals with 1GHz bandwidth

- ✦ Benefits
 - ✦ Clean, Crisp Waveforms
 - ✦ More Signal Details
 - ✦ Precise Waveform Measurements

Introducing the Teledyne LeCroy HDO8000 Oscilloscope

✦ *Further*

- ✦ 8 analog input channels
 - ✦ Ideal for high power and three-phase power electronics analysis
 - ✦ Very useful for deeply embedded electronic/mechatronic systems

✦ *Finer*

- ✦ 12-bit HD4096 High Definition Technology
 - ✦ “16x closer to perfect”


✦ *Faster*

- ✦ Up to 1 GHz
 - ✦ Bandwidth for today's **and** tomorrow's technologies



HD4096 12-bit technology is being deployed into 8 channels to meet the needs of fast growing applications

Traditional High Channel Count Setup: Coherent Modulation Measurements, 2009-2010



LabMaster 10-100 Zi 100 GHz Real Time Bandwidth

- ✦ Starting at 25 GHz bandwidth
- ✦ The highest bandwidth: Up to 100 GHz
- ✦ The fastest sample rate: Up to 240 GS/s
- ✦ The highest channel count:
 - ✦ Up to 80 channels @ 36 GHz
 - ✦ Up to 40 channels @ 65 GHz
 - ✦ Up to 20 channels @ 100 GHz




60 Channel 10Zi System at NY Factory



Track View


Frequency is measured and plotted for each cycle




- ✦ Histograms reveal statistical distribution of values, but they contain no timing information
- ✦ Track View plots the value of a measurement versus time
- ✦ Track waveform values are calculated cycle by cycle
- ✦ Track waveform is time coincident with source waveform

Frequency of Track plot reveals FM modulation rate of 100 kHz

Track of Frequency Reveals Shape of Velocity Curve






User-Defined Custom Measurements




Custom parameters are selected from the measurement menu like any standard parameter. Supports MATLAB, C/C++, Visual Basic Script, VBA, MS Excel, and JavaScript

User-Defined Custom Math


Custom math functions are selected from the math setup menu like any standard function. Script is entered in




In-Line Custom Math and Measurements



MATLAB Spectrogram on Scope



Create Custom Math Functions with Excel




Acquired Trace



Trace generated in Excel

Measurements on Excel-generated trace

MATLAB Measurements



- ✦ Custom MATLAB parameter finds the half-life of the damped sine wave
- ✦ The value 3.149 is the number of cycles that have occurred when the signal reaches 50% of its peak amplitude