

PDV Probe Design with Stereo Imaging

Robert M. Malone, Brian M. Cata, Brent C. Frogget,
Morris I. Kaufman, and Vincent T. Romero


National Security Technologies, LLC
Los Alamos Operations
P.O. Box 809, Los Alamos, NM 87544

For 7th Annual PDV Workshop
October 22–23, 2012
Albuquerque, NM

This work was done by National Security Technologies, LLC, under
Contract No. DE-AC52-06NA25946 with the U.S. Department of Energy.



Multiple lens array probe for hemisphere experiments




(a) Without multi-faceted prism

(b) With prism

(c) Fiber points in zone coverage (zone positions can be changed if prism face angles are changed or zones rotated)


PDV fisheye lens ray trace - features





Features:

- Light incident normal to optical fibers
- Index match to optical fibers to reduce back reflections
- Distance from index-matched element and fibers can be adjusted for fine focusing
- Needs good anti-reflection lens element coatings and limited number of elements

Fisheye probe ferrule and lens assembly




(View direction
in slide 3)




Tip shown is about halfway down tube at left;
the inner tube slides in or out to adjust.


AOC 2: Fisheye with mounting for longer reflector prisms




Ferrule for fibers and completed assembly




Ten 12-fiber ribbons
plus six multimode fibers



Fisheye probe with a line of 126-micron spaced fibers




PDV probe with stereo imaging for hemisphere



Record PDV from 100 down to 7 mm.

Altering prism angle sets viewing below the horizon.

PDV probe with stereo imaging for hemisphere



25 mm diameter zone for imaging (blue & black rays).
F/# of surface collected light is 15.

100 mm

Record PDV from 100 down to 7 mm.



2.4 mm diameter coherent bundles




25 mm diameter zone for imaging (blue & black rays).
F/# of surface collected light is 15.

Zone 3 & 6 are used for stereo imaging

Assuming 24 mm diameter FOV at surface and 2.4 mm diameter bundle, @ 50 lp/mm. Resolve 200 μ m at surface (5 lp/mm).



Fiber arrays are translated 0.36 mm, so that the image areas overlap.




1 of 6 illumination bundles

2 prism facets are tilted at 56° and 2 at 61°

Slice view on next slide

← →
Coherent bundles offset to allow overlap imaging





Placing 2 of the 2.5 mm diameter bundles plus 6 of the 1.5 mm illumination bundles leaves room for **> 346 PDV fibers** (ignoring fibers that touch anything).
 AOC probe can only image 2.4 mm diameter.
 Cutoff switches line the inside of the 6.5 mm ID pipe.

FIBER PACKING PROGRAM DATA

Output Data

Packed fiber number =2017

Packing Configuration


Hexagonal Close Pack

Input Data

Tube Diameter (mm) =6.5
 Coating Diameter (um) =135
 Cladding Diameter (um) =80
 Core Diameter (um) =10

Area (Square mm)

Tube	=33.18	
Coating	=18.73	(56.5%)
Cladding	=9.98	(30.1%)
Core	=0.1584	(0.477%)
Dead Area	=4.312	(13%)






Region reserved for cutoff switch overlap.

Zone 7 (through prism hole).
Same lenses used for Zone 1,2,4, & 5.

Magnification = 43

Array movement = 43^2 x image movement

Custom lenses




rays going in and out of page

15.00 MM

AOC V52 Z7.len

RMM 11-Oct-12





AOC_V52_Z7.len

RMM 22-Sep-12

These rays go through the hole in the pyramid prism (not shown)


3D view of tilted array





1 out of 15 fibers from Z1 fall outside 1.5 mm diameter zero crossing volume.

Zone 3 & 6 are used for stereo imaging (500-700 nm)



AOC_v52_z3_imaging.len

RMM 23-Sep-12

AOC_v52_z3_imaging.1
en

DIFFRACTION MTF


RMM

24-Sep-12

DIFFRACTION LIMIT	
---	Y 0.00 mm @ bundle
---	X 0.00 mm @ bundle
---	Y 0.30 mm @ bundle
---	X 0.30 mm @ bundle
---	Y 0.60 mm @ bundle
---	X 0.60 mm @ bundle
---	Y 0.90 mm @ bundle
---	X 0.90 mm @ bundle
---	Y 1.20 mm @ bundle
---	X 1.20 mm @ bundle


WAVELENGTH	WEIGHT
1550.0 NM	0
700.0 NM	1
600.0 NM	1
500.0 NM	1


FREQUENCY 5 C/MM




Assuming 24 mm diameter FOV at surface
and 2.4 mm diameter bundle, @ 5 lp/mm.
Resolve 200 μ m at surface (5 lp/mm).

2 prism facets are tilted at 56° and 4 at 61°






Bug-eye probe used for Hemi shot #3




Enhance aluminum coating on BK7 glass prism

17.35 mm diameter metal housing

Second attempt with correctly oriented fiber arrays. Two alignment marks rotated 180°.




Fiber rotation and cleaning are issues.




Bug eye probe used for Hemi shot #3 (later redone).

Reflected label off prism facet

90° azimuth




Efficiency measurement of each fiber channel can be measured versus their tracking distance. The diffuse reflector is on a computer-controlled motorized mount. Probe is in rotatable mount.



Moveable diffuse reflector


The efficiencies of each fiber can vary in shape and magnitude.

Fisheye Hemi-2 event, 8/2011



Advantages:

1. Accommodates imaging along with the PDV channels. Imaging does not have to be used for dynamic recording, it could also serve as a surface inspection tool. We have a 1550 nm converter for visible cameras allowing images of surface features surrounding a PDV spot.
2. Each of the 5 fiber arrays can have different rotations to change area coverages.
3. Each mirror facet can have different tilts to change area coverages. We used 56° and 61° on first design.
4. Data recorded down to **7.0 mm** from the zero crossing.
5. This probe accommodates several hundreds of fibers.
6. Each lens stack can have different focal lengths. (modular design)
7. Future probe design will use Fused Silica lens and flat coupled fiber array.



Disadvantages:

1. Extra assembly time required to angle polish each fiber (add one extra week).
2. Zero crossings are shifted ~ 2.5 -mm for 4 of the 5 zones.
3. Must show that imaging is cheap and easy to perform.