


PDV Probe Designed with Stereo Imaging

Robert M. Malone, Brian M. Cata, Thomas H Conwell,
Brent C. Frogget, Morris I. Kaufman, and Vincent T. Romero


National Security Technologies, LLC
Los Alamos Operations
P.O. Box 809, Los Alamos, NM 87544

For 8th Annual PDV Workshop
June 24-26, 2014
Las Vegas, NV

This work was done by National Security Technologies, LLC, under
Contract No. DE-AC52-06NA25946 with the U.S. Department of Energy.




Multiple lens array probe for hemisphere experiments, 9/2011




Using 4 mm diameter lenses

- (a) Without multi-faceted prism
- (b) With prism
- (c) Fiber points in zone coverage (zone positions can be changed if prism face angles are changed or zones rotated)



Need smaller than a dime !!

Complete system



PDV fiber arrays are index matched to first fused silica lens.


Zones 3 & 6 are used for stereo imaging

The stop diameter determines the NA of collected light and also the depth of focus

(Perspective has been rotated)

Assuming 24 mm diameter FOV at surface and 2.4 mm diameter bundle at 50 lp/mm. Resolve 200 μm at surface (5 lp/mm).


2 thin stop "washers" rest on top of prism



24 mm diameter zone for imaging (blue & black rays); 10x magnification


F/# of surface collected light is 36

Imaging stop




Coherent bundles are translated 0.314 mm, so that the image areas overlap.

PDV only system




Partial PDV system



Altering prism angle sets viewing below the horizon




2 prism facets are tilted at 56° and 4 at 61°



Imaging baffle sleeve



Imaging stop





1.5 mm dia.
Illumination fibers (6)



Edges of prism trimmed to 12 mm diameter







1 of 6 illumination bundles

2 prism facets are tilted at 56°
4 tilted at 61°

← →
Coherent bundles offset to allow overlap imaging



Placing 2 of the 2.5 mm diameter bundles plus 6 of the 1.5 mm illumination bundles leaves room for **>346 PDV fibers** (ignoring fibers that touch anything).
 AOC probe can only image 2.4 mm diameter.
 Cutoff switches line the inside of the 6.5 mm ID pipe.

FIBER PACKING PROGRAM DATA

Output Data

Packed fiber number =2017

Packing Configuration


Hexagonal Close Pack

Input Data


Tube Diameter (mm) =6.5
 Coating Diameter (um) =135
 Cladding Diameter (um) =80
 Core Diameter (um) =10

Area (Square mm)


Tube	=33.18	
Coating	=18.73	(56.5%)
Cladding	=9.98	(30.1%)
Core	=0.1584	(0.477%)
Dead Area	=4.312	(13%)



Region reserved for cutoff switch overlap.



Zone 7 (through prism hole).
Same lenses used for Zones 1, 2, 4, & 5.




AOC V61 Z7.1en

Fiber array has been rotated 11.9°

RMM 12-Jun-14



Zones 1, 4 (without fold mirror)




AOC V61 Z1.1en

Fiber array has been rotated 22°

RMM 12-Jun-14






AOC V61 Z7.1en


RMM 12-Jun-14

Fibers can be positioned anywhere inside this 2.0 mm diameter circle




Zone 7

Zone 7



Fibers can be positioned anywhere inside this 2.0 mm diameter circle



Zones 1, 4

Fiber array has been rotated 22°

.350 MM

SURFACE 5 :facet gamma rotation

RMM 17-Jun-14




Nevada National Security Site
Managed and Operated by

AOC V61 Z1.1en



Fibers can be positioned anywhere inside this 2.0 mm diameter circle



Zones 2, 5

Fiber array has been rotated 45°

.350 MM

SURFACE 6

RMM 17-Jun-14




Nevada National Security Site
Managed and Operated by

AOC V61 2-angle prism stereo-imaging.len




Zones 3 & 6 are used for stereo imaging (500–700 nm)

Coherent bundle is offset 0.314 mm



11.00 MM



Zones 3, 6

RMM 12-Jun-14

AOC V61 Z3 imaging.len

Fibers collect with 0.14 NA

Cemented doublet

Cemented doublet

YZ view

3.0 mm

3.5 mm

Limits NA of collected light

3.0 mm

XZ view

S-TIH14

S-NSL36

S-LAL18

S-PHM52


S-LAH60

1.40 MM

AOC V61 Z3 imaging.len


RMM 12-Jun-14

Diffraction MTF
AOC_V61_Z3_imaging.len



Diffraction MTF
AOC_V61_Z3_imaging.len

Changing the collected light NA will change the depth of focus



14 mm in front


Best focus

Target surface

5 lp/mm resolution is maintained over 14 mm of travel

14.0 mm

Assuming 24 mm diameter FOV at surface and 2.4 mm diameter bundle at 50 lp/mm. Resolve 200 μm at surface (5 lp/mm).



Advantages:

1. Accommodates imaging along with the PDV channels. Imaging does not have to be used for dynamic recording, it could also serve as a surface inspection tool. We have a 1550 nm converter for visible cameras allowing images of surface features surrounding a PDV spot.
2. Each of the 5 fiber arrays can have different rotations to change area coverages.
3. Each mirror facet can have different tilts to change area coverages. Currently using 56° and 61°.
4. AR coatings more efficient than fish-eye, because of fewer curvatures.
5. Each lens stack can have different focal lengths (modular design).
6. This probe accommodates several hundreds of fibers.
7. Data recorded down to **6.5 mm** from the zero crossing.

Disadvantages:

1. Zero crossings are shifted ~2.5 mm for 4 of the 5 zones.
2. Must show that imaging is cheap and easy to perform.

